


# 200T MIXER



## OPERATORS HANDBOOK & PARTS

**Manual V602069**      *printed May 2011*  
(This publication includes Manual WMANS544)  
Up to Machine Serial No 1332

# WINGET

WINGET LIMITED, P.O. Box 41, Edgefold Industrial Estate, Plodder Lane, Bolton, BL4 0LS, England  
Tel: +44 (0) 1204 854650      Fax: +44 (0) 1204 854663  
[www.winget.co.uk](http://www.winget.co.uk)

**CONTENTS**

<b>Section</b>	<b>Page</b>	<b>Section</b>	<b>Page</b>
<b>INTRODUCTION</b>		<b>TECHNICAL INFORMATION</b>	
Introduction	II	Lubricants	4.1
Warranty	III	Noise levels	4.1
Safe Working	1.1	Drum speed	4.1
Decals	1.3	Mixer drum sealant	4.1
Lashing down & lifting points	1.6	Engines & motors	4.1
<b>OPERATION</b>		Dimensions	4.2
Installation	2.1	Electrically driven mixers wiring	4.3
Lister-Petter LT1/LV1-10 engines	2.2	Yanmar L40/L48 ARE-SE key start wiring	4.4
Yanmar L40/L48 ARE-SE engines	2.4	<b>PARTS</b>	
Electric motors	2.7	Illustrations of all mixer components	
Mixer drum positions	2.7		
Mixing	2.7		
End of work procedures	2.8		
<b>SERVICING</b>			
Service schedule	3.1		
Greasing & lubrication	3.2		
Drum drive	3.2		
Bolt torques	3.3		
Engines:			
<i>(Lister-Petter only. For Yanmar engines, see separate Operator's Manual)</i>			
Air cleaner	3.3		
Engine lubrication oil	3.4		
Fuel filter & priming the fuel system	3.5		
Battery	3.6		
Mixer drum assembly	3.7		
Mixer drum drive overhaul	3.9		

## The Handbook

The contents of this Handbook, although correct at the time of publication may be subject to alteration by the Manufacturers without notice. Winget Limited operate a policy of continuous product development. Therefore, some illustrations or text within this publication may differ from your machine.

**WARNING**

*The operator must read all the Handbook and fully understand its contents before attempting to operate the machine.*

THE HANDBOOK MUST NOT BE REMOVED FROM THE MACHINE.

The Handbook must be kept clean and in good condition. Additional copies of the Handbook can be obtained from your Distributor.

The contents of this Operator's Handbook are designed as a guide to the machine's controls, operation, working capacities and maintenance. It is **not** a training manual.

Only trained operators should use this machine. Contact the C.I.T.B. or equivalent body for advice on training.

**WARNING**

In this Handbook are **WARNING** notes. They are preceded by this symbol:

**WARNING**

*These notes are used to indicate the procedure being described in the Handbook must be followed to avoid serious injury or death to yourself or to others, or damage to the machine.*

*The warnings are also used to protect the machine from unsafe servicing practices.*

Pay particular attention to the warnings given in the Handbook.

If you have any doubts about any aspect of the machine's capability or servicing procedures, you must consult the manufacturer.

## **Warranty terms & conditions**

The Manufacturer assures you that if any part of the machine becomes defective due to faulty manufacture or materials within 12 months from the date of purchase, the part will be repaired or replaced under warranty free of charge by any authorised Winget Distributor. Warranty repairs **must** be carried out by Winget Distributors.

This Warranty is given to the first owner and may be transferred to subsequent owners for the balance of the Warranty period.

The Manufacturer's liability only extends to the costs of repair or replacement of the faulty parts and necessary labour charges involved in the repairs. The Company accepts no liability for any consequential loss, damage or injury, resulting directly or indirectly from any defect in the goods.

Items not covered by Warranty and considered to be the customer's responsibility include normal maintenance services; replacement of service items and consumables; replacement required due to abuse, accident, misuse or improper operation; replacement of wearable items e.g. pins, bushes, brake linings, clutch linings etc.

The Warranty will not apply where the equipment is modified, converted, or used for purposes other than those for which it was designed, unless clearance for the modifications etc. have been granted by the Manufacturer, in writing.

The Pre-Delivery Inspection and Warranty Registration Document must be completed correctly and returned to the Manufacturer within 7 days of sale date. Failure to do so may result in the claim being subsequently rejected.

Tyres and tubes are not covered by Warranty, but are covered by the tyre manufacturer's own warranty system which provides against defects in material or workmanship. Engines are covered separately by the engine manufacturers, and engine warranty repairs must be handled by the relevant engine manufacturers' distributors.

No claim will be considered if other than genuine Winget Limited parts, which must be obtained from Winget Limited via an authorised Distributor, are used to effect a repair, or if lubricants other than those recommended by Winget Limited are used.

The equipment must be serviced in accordance with the service schedules laid down by Winget Limited. Evidence that these have been complied with may be required before Warranty Claims are reimbursed.

The Manufacturer's policy is one of continuous improvement. Winget Limited reserve the right to change specifications without notice. No responsibility will be accepted for discrepancies which may occur between specification of machines and the descriptions contained in publications.



Safety is the responsibility of the persons working with this machine. Think “safety” at all times. ***Read and remember the contents of this Handbook.***

## **MACHINE MODIFICATION**

**WARNING** Any modifications to the machine will affect its working parameters and safety factors. Refer to the Manufacturers before fitting any non-standard equipment or parts.



The manufacturers accept no responsibility for any modifications made after the machine has left the factory, unless previously agreed by the Manufacturers in writing. The Manufacturers will accept no liability for damage to property, personnel or the machine if failure is brought about due to such modifications, or fitment of spurious parts.

## **OPERATION**

**WARNING** Only trained operators should use this machine.



Always be aware of local and national regulations governing the use of the machine.

Always ensure that all guards are in position and correctly fitted.

***Electrically driven mixers:*** Always ensure that the power supply has been correctly connected by a qualified electrician.

Electrical cables must be of a suitably armoured type. Ensure that they are protected from damage and not liable to be tripped over.

Do not connect to a household socket!

Use only with an RCD protected supply. Only connect via special feeding point (e.g. power distribution panel on building site with fault-current-breaker).

Only authorised persons should be allowed to operate the mixer, or be in the immediate area.

Never add fuel or lubricant to the machine while it is running.

Keep the area around the machine clear of obstructions which could cause persons to fall onto moving parts.

Keep the body and clothing clear of all moving and hot parts.

Always ensure that during operation the mixer is standing on stable and level ground and that the wheels are chocked.

Keep the engine/motor housing lid closed when the engine or electric motor are running.

.

**ENGINE****WARNING**

Starting any diesel engine can be dangerous in the hands of inexperienced people. Operators must be instructed in the correct procedures before attempting to start any engine.

Always obtain advice before mixing oils; some oils are not compatible. If in doubt, drain and refill.

The materials used in the manufacture and treatment of some filters and elements may cause irritation or discomfort if they come into contact with the eyes or mouth and they may give off toxic gases if they are burnt.

Engine lifting eyes must not be used to lift the complete machine.

Ether based cold start aids in aerosol cans must not be used under any circumstances.

**EXHAUST GASES CONTAIN CARBON MONOXIDE WHICH IS A COLOURLESS, ODOURLESS AND POISONOUS GAS THAT CAN CAUSE UNCONSCIOUSNESS AND DEATH.**

**ELECTRICAL SYSTEMS****WARNING**

Starting engines that are fitted with charge windings/alternators which have been disconnected from the battery may cause irreparable damage.

The following points must be strictly observed when charge windings are fitted otherwise serious damage can be done.

Never remove any electrical cable while the battery is connected in the circuit.

Only disconnect the battery with the engine stopped and all switches in the OFF position.

Always ensure that cables are fitted to their correct terminals. A short circuit or reversal of polarity will ruin diodes and transistors.

Never connect a battery into the system without checking that the voltage and polarity are correct.

Never flash any connection to check the current flow.

Never experiment with any adjustments or repairs to the system.

The battery and charge windings/alternators must be disconnected before commencing any electric welding when a pole strap is directly or indirectly connected to the engine.

**BATTERIES CONTAIN SULPHURIC ACID WHICH CAN CAUSE SEVERE BURNS AND PRODUCE EXPLOSIVE GASES.** If the acid has been splashed on the skin, eyes or clothes flush with copious amounts of fresh water and seek immediate medical aid.

## SERVICING & MAINTENANCE

### WARNING



Never allow unqualified personnel to attempt to remove or replace any part of the machine, or anyone to remove large or heavy components without adequate lifting equipment.

Before maintenance work is begun, ensure that the engine is stopped, or that the electric motor is switched off, and isolated from the mains.

Always conform to service schedules except when an emergency calls for immediate action, or adverse conditions necessitate more frequent servicing.

Always report any defect at once, before an accident or consequential damage can occur.

On completion of maintenance, check that the machine functions correctly, and that all guards are correctly fitted.

**Disposal of waste oil.** Dispose of waste oil into waste oil storage tanks. If storage tanks are not available, consult your Distributor or local authority for addresses of local designated disposal points. It is illegal to dispose of waste oil into drains or water courses, or to bury it.

## DECALS


Ensure that all warning decals fitted to the mixer are legible. If any should become detached, they must be replaced immediately.

**Descriptions of the pictorial decals are as follows:**

Fuel tank filling point.




Read Operators Handbook, or Operators Handbook storage place.



Attach lifting hooks to this eye.




The battery negative terminal is connected to earth.




Remove starting handle.



Battery isolator.




Beware of electrical hazards.



Wear ear protection.




Engine stop.



Wear eye protection.




Keep clear of chain drives.



These surfaces may be hot.



Conforms to EEC standards.




Keep hands clear of drum.




**ISO 8999 safety symbols used with Lister/Petter engines**



Read the handbook




Stop control (on engine)




Diesel fuel fill




Engine oil fill




Engine oil level




Engine oil pressure




Anti-clockwise rotation




Clockwise rotation




Lifting eye - engine only



On



Off



Pre-heat



Rotational speed control




Linear speed control



Tachometer




Elapsed hours



Battery charging



Engine cranking



Electrical hazards



General hot surface warning

## Lashing down & lifting points

### General

Care should be taken when lifting or transporting the mixer to ensure that lifting or retaining straps are in good condition and the following procedures must be followed when lifting or lashing down to avoid causing unnecessary damage.

It is recommended that chains or webbing slings are used to lift the mixer via the lifting eye on the mainframe **(A)** and that ratchet type webbing straps are used to lash the mixer down.

### Lifting the Mixer (Crane)

Using the tilting handwheel and locking plunger, lock the drum upright as illustrated.

To prevent the drawbar swinging freely as the mixer clears the ground, lash it up to the handwheel **(B)**.

If the mixer is on site and the wheels are immersed in dried concrete or mortar the wheels must be freed before attempts are made to lift the mixer.

Attach suitable lifting equipment to the lifting eye **(A)** and slowly take the weight.


Do not 'snatch' the mixer otherwise damage may be caused to the lifting eye or lifting equipment.

Be aware that the mixer will tend to swing as it clears the ground.

### Lifting the Mixer (Forklift/Telehandler)

Using the tilting handwheel and locking plunger, lock the drum upright as illustrated.

If the wheels are immersed in dried concrete or mortar, free them before attempting to lift the mixer.



Spread the fork tines and carefully position them so that they pass through the brackets **(C)** that are attached to the mainframe.

Position the carriage as close as possible to the mixer

Slowly tilt the carriage back slightly to prevent the mixer rocking forward, then raise the mixer just clear of the ground.

Do not raise the mixer unnecessarily high. Keep the height to the minimum required to clear any obstructions without unduly obstructing your forward vision.

When travelling keep your speed to the minimum and when loading vehicles do not raise the mixer to the height of the bed until the mixer is close to the vehicle.

Similarly when unloading vehicles lower the mixer just clear of the ground as soon as it clears the side of the vehicle.

### Lashing down

The drum should be locked in the upright position, as illustrated, to keep the centre of gravity as low as possible.

It is recommended that unless the mixer is pulled up against a headboard or some form of substantial wheel chocks that two ratchet type webbing straps are used to retain the mixer, one pulling to the rear and one pulling to the front.


Position the mixer on the vehicle bed and chock the rear wheels to prevent it rolling until lashed down.

Turn the front axle so that the drawbar **(F)** is below the mixer and not forming an obstruction on the vehicle bed.

Pass one of the webbing straps between the drum and trunnion at point **(D)** and secure the strap down to retaining hooks on the vehicle bed in front of the mixer.

Pass the second strap between the drum and trunnion at point **(E)** and secure the strap down to retaining hooks on the vehicle bed to the rear of the mixer.

Tighten the straps by means of the ratchets until the mixer is securely held.





## Installing the mixer on site

Welded to the mixer are lifting points. These are provided to assist with loading or unloading the mixer and for transportation across site.

**WARNING** *For mixer weights, see "Specifications"*



Never carry mixers by their lifting points on public roads.

Do not tow mixers across uneven ground.

The ground on which the mixer stands must be level and stable. Ensure that the wheels are chocked.

### **Electrically driven mixers:**

Always ensure that the power supply is correctly connected or disconnected by a qualified electrician.

Electrical cables must be of a suitably armoured type. Ensure that they are protected from damage and are not liable to be tripped over.

Do not connect to a household socket!

Use only with an RCD protected supply. Only connect via special feeding point (e.g. power distribution panel on building site with fault-current-breaker).

## Engine operation

**WARNING** *As soon as the engine has started the mixing drum will begin to rotate.*



### **Before starting the engine:**

Ensure the engine and drum are free to turn without obstruction.

Check that the lubricating oil level is correct. The oil sump must be filled to the 'full' mark on the dipstick; do not overfill.

Check that the fuel supply is adequate and the system is primed.

### **Electric key start machines only:**

Ensure that the battery is connected, fully charged and serviceable.

## Engine Safety

**WARNING** *The following pages of engine operating instructions are of a general nature and should be read in conjunction with, or substituted by the engine Manufacturer's instructions.*



*Starting any diesel engine can be dangerous in the hands of inexperienced people.*

*Before attempting to start any engine the operator should read the 'Safe Working' section of this book and be conversant with the use of the engine controls and the correct starting procedures.*


**ETHER BASED COLD START AIDS IN AEROSOL CANS MUST NOT BE USED UNDER ANY CIRCUMSTANCES.**

**EXHAUST GASES CONTAIN CARBON MONOXIDE WHICH IS A COLOURLESS, ODOURLESS AND POISONOUS GAS THAT CAN CAUSE UNCONSCIOUSNESS AND DEATH.**

## LT1-10/LV1-10 engines

### Description

- A Dipstick
- B Lubricating oil filler
- C Engine control
- D Decompressor lever
- F Fuel tank




### The cold start aid (*where fitted*)

The cold start aid is fitted to the combustion air intake port and is used when the ambient temperature is below -10 deg.C (14 deg.F).

With the fuel turned on, turn the engine for up to 20 revolutions to prime the fuel and lubrication systems.

Withdraw the plunger (A) and fill one third of the cup (B) with the same type of lubricating oil as used in the engine.

Replace the plunger and inject the oil just before starting the engine.



**WARNING** *The device must not be used more than three times in succession during the same attempt to start the engine.*




### The starting handle(s)

A non-limited kick-back handle (C) or limited kick-back handle (D) system may be fitted to the engine.

The two handles are not interchangeable and care must be taken to ensure the correct type is retained with the engine.

Always use the correct starting handle which has been designed for the engine.



Ensure there are no burrs on the handle.

Before attempting to use the handle, clean and lightly oil that part of it which fits onto the engine.

### Hand starting the engine

Select the excess fuel position by gently pulling the engine control lever (**L**) outward over the middle catch (**M**) and turning it fully clockwise.

Move the decompressor lever towards the flywheel (**N**).



Insert the correct handle (See: 'Starting handles') into the starting housing.

Turn the engine slowly for up to 20 turns to prime the combustion chamber and lubricating oil system.

Maintaining a firm grip on the starting handle, crank the engine really fast and when sufficient speed is obtained move the decompressor lever towards the gear end and continue to crank until the engine fires.

Retain a firm grip on the handle and remove it from the engine.

Close the engine lid and ensure that it stays closed while the engine is running.



**WARNING** *Do not stop the engine with a load in the drum.*



### Stopping the engine

Turn the engine control anti-clockwise to the STOP position and hold it there until the engine comes to rest.

**WARNING** *Never stop the engine by using the decompressor lever, or valve damage may occur.*



## Yanmar L40/L48 ARE-SE

### Description

- A Fuel cock
- B Engine speed lever
- E Starting key

### Electric starting the engine

Open the fuel cock (A). Put the engine start lever to the RUN position (B).

Turn the starting key (E) clockwise to START position.

Remove your hand from the key as soon as the engine starts.

If the engine does not start after 10 seconds, wait for another 15 seconds before attempting to start again.

#### WARNING



*If the starter motor is turned for too long, the battery will go flat and motor seizure will occur. Always leave the starting key turned on, in the ON position, while the engine is running.*

*Check monthly that the battery fluid is at the correct level.*

### Cold Starting





In cold weather, if the engine is hard to start, remove the rubber plug of the rocker arm cover and add 2cc of engine oil before starting. *Do not add more than 2cc of engine oil to prevent internal engine damage.*

#### WARNING



*Never use any cold starting aids such as ether (Easy start), gasoline, paint ether or other volatile liquid or gas.*

*Keep the rubber plug in the cover except when adding oil.*



*If the plug is not in place, rain, dirt and other contaminants may enter the engine and cause accelerated wear of internal parts.*

## Yanmar L40/L48 ARE-SE

### Stopping the engine

Return the engine speed lever to the STOP position.

**Note:** On later engines it is necessary to depress the red button on the stop control to release this control into the STOP position.

With electric-start engines, turn the starter key to the OFF position.

Set the fuel cock lever to the CLOSED position.

Slowly pull out the recoil handle until pressure is felt (that is, to the point in the compression stroke where the intake and exhaust valves are closed), and leave the handle in this position. This prevents rust from forming while the engine is not in use.

#### WARNING



*If the engine keeps on running even after the speed lever is placed at STOP position, stop the engine by closing the fuel cock.*


*Do not stop the engine with the decompression lever.*

## Yanmar L40/L48 ARE-SE

### Manual starting in the event of a flat battery

#### Description

- A Fuel cock
- B Engine speed lever
- C Decompression lever
- D Recoil starting handle



#### Starting the engine

Open the fuel cock **(A)**.

Put the engine start lever to the RUN position **(B)**.

Turn the start key to ON.

Pull out the recoil starting handle **(D)** slowly until you feel a strong resistance, then return it to the initial position.





Push down the decompression lever **(C)**. It will return automatically when the recoil starter is pulled.

Grip the recoil starting handle **(D)** firmly with both hands. Pull the rope hard and fast. Pull it all the way out.

The engine should now have started. If it has not, repeat the procedure.

#### Cold Starting

In cold weather, if the engine is hard to start, use the same cold start procedure as described on page 2.4.



## Electric motors


### To start and stop:

Gain access to start button by raising the motor cover (50).

Start the motor by pressing button (51). Lower the motor cover (50).

To stop the motor, press button (52). (Pressing button (53) will also stop it.)

**WARNING** *In an EMERGENCY, press button (52) to stop the motor.*



## Before mixing

The operator must calculate the correct percentages of water and aggregates to be mixed.

**WARNING** *Cements can cause skin irritation; wear protective clothing.*





## Mixer drum positions

The locking plunger (54) holds the mixing drum in one of the following positions *Charge and Mix (1)* or *Discharge (2)*.

**To release the handwheel:** Rotate the plunger (A) until the cross-pin (B) aligns with the slot (C), then pull the plunger outwards (D).

**To lock the handwheel:** Align the plunger with the appropriate hole in the frame, then push (E) and rotate the plunger until the cross-pin is vertical (F).



## Mixing

Turn the drum to *Charge and Mix* position (1).

With the mixer running; charge the drum with the correct percentages of water and aggregates, then allow mixing to continue for about two minutes.

Ensure that a suitable container has been positioned by the side of the mixer to catch the discharging load.

Turn the drum to *Discharge (2)*, and allow the load to run into the container.

### **At the end of the working day**

- A** Thoroughly clean out the mixing drum with water and gravel.
- B** Stop engine, and remove the starting handle to prevent unauthorised use of the machine.
- C** Grease the machine.
- D** If the mixer has a diesel engine, fill the fuel tank.
- E** If the mixer has an electric motor, it must be isolated from the mains.

## SERVICE SCHEDULE

(See also the relevant Engine Workshop Manual)

**YANMAR L40 ENGINE**  
For servicing the Yanmar L40/L48 engine, see the engine Operation Manual

<b>Every day</b>	
Links & hinges:	Lubricate.
Shafts & bearings:	Lubricate.
Engine: (see Engine Manual)	Check fuel and lubricating oil levels. Check for oil and fuel leaks. Clean/replace air cleaner element under very dusty conditions

<b>Every week (or 50 hours running) The above and following items</b>	
Nuts, bolts and keys.	Tighten (Each week for first month).
Drive chains:	Lubricate & check tension, check V belt tension on ES engines..
Drum Bevel Gears:	Lubricate with open gear fluid.

<b>Every 125 hours. The above and following items</b>	
Engine:	Clean/replace air cleaner element under moderately dusty conditions.
Battery (where fitted):	Check condition.

<b>Every 250 hours. The above and following items</b>	
Nuts, bolts & keys:	Tighten.
Engine:	Change lubricating oil. Check valve clearance. (see Engine Manual). Clean/replace injectors if exhaust is dirty. (see Engine Manual) Renew fuel filter element if the fuel is not perfectly clean.

<b>Every 500 hours. The above and following items</b>	
Engine:	Replace air cleaner element. Check exhaust and induction for leaks, damage or restrictions. Renew fuel filter element. Check battery charge winding system. (see Engine Manual)

<b>Every 1000 hours. The above and following items</b>	
Engine: (see Engine Manual)	Decarbonise if the engine performance has deteriorated. Clean cylinder barrel and head fins. Clean restrictor banjo union at the cylinder head end of the oil feed pipe. Flush and refill fuel tank.

<b>Every 5000 hours. The above and following items</b>	
Engine:	Major overhaul, if necessary. (see Engine Manual)

## SERVICING PROCEDURE

### Greasing and lubrication

**WARNING** *It is essential that oils and grease used for servicing do not become contaminated with sand or cement dust.*



#### Every day

Apply a little engine oil to pins, joints and hinges etc. to ensure that they move easily and are free from corrosion.

Shafts and bearings fitted with grease nipples must be greased using a good quality medium grease.

Bearings must not be allowed to run dry. When greasing it is better to give a little frequently rather than a lot at long intervals.

### Drum drive

#### *Every week (or 50 hours running)*


Lubricate drive chains (**A**) with a little engine oil. (Do not oil the belts of electrically driven machines.)

Check the tension of the chains and adjust if necessary as follows:

- 1 On the slack side of the chain there should be free movement equal to the length of one pitch of the chain.  
i.e. If the pitch of the chain is 20mm, then the movement on the slack side should be 20mm.
- 2 Never over-tighten the chain as this will put excessive strain on engine bearings causing vibration and wear.

#### Lubrication Points

		Number of points
A	Drive chains	Oil 2
B	Trunnion pivots	Grease 2
C	Tilt chain	Oil 1
D	Wheels (pneumatic tyres)	Grease 4
E	Steering joint	Oil 1
F	Tilt wheel	Grease 1



## Bolt torques

***Every week for the first month, then every three months***

Check the tightness of all bolts, nuts, and keys etc. Pay particular attention to engine mounting bolts.

## Engine, general servicing

Under very dusty conditions, air cleaners, lubricating oil and fuel filters will require more frequent attention. (see the "Service Schedule" on page 3.1)

**WARNING** *The materials used in the manufacture and treatment of some filters and elements may cause irritation or discomfort if they come into contact with the eyes or mouth and they may give off toxic gases if they are burnt.*




## Air cleaner

***Every day or 125 hours (see schedule)***

**Change the LT1-10/LV1-10 air cleaner as follows:**

Remove the cover (**D**) by removing the centre bolt.

Remove the old element (**E**) and fit a new one.



## Engine lubrication oil

### *Every day*

Check lubrication oil level with the dipstick. Top up if necessary.

### *Every 250 hours*

Drain and refill the oil sump as follows:

#### WARNING



*Dispose of waste oil into waste oil storage tanks. If storage tanks are not available, consult your Distributor or local authority for addresses of local designated disposal points. It is illegal to dispose of waste oil into drains or water courses, or to bury it.*

*Oils and fuels can cause skin irritation. Wear suitable protective clothing to prevent skin contact.*


If possible run the engine immediately before draining the oil.

**Note:** During 2003 the metal drain pipe **(B)** was replaced by a flexible drain hose (not illustrated).

Place a suitable container under the drain plug. Remove the drain plug **(A)** and drain oil.

Clean and coat the threads of the drain plug with Hylomar PL32/M or Three Bond 1110B.

Replace the drain plug **(A)** taking care not to overtighten it.




## Fuel filter

*Every 250 hours or 500 hours (see schedule)*

*Before changing the filter read the warnings in the "Safe working" section of this handbook.*


**Change LT1-10/LV1-10 fuel filters as follows:**

- Remove the retaining bolt or plug **(H)**.
- Remove the old element **(I)** and joints **(J)**.
- Fit a new element and new joints.
- Replace and tighten the retaining bolt or plug **(H)**.
- Prime the fuel system.



**Prime LT1-10/LV1-10 fuel system as follows:**

- Fill the fuel tank.
- Move the engine control lever to the 'RUN' position.
- Vent the filter through bleed screw **(G)** until a full air free flow of fuel is obtained.
- Vent fuel through the pump bleed screw **(K)** until a full air free flow of fuel is obtained.



## Battery

**WARNING**

*BATTERIES CONTAIN  
SULPHURIC ACID WHICH  
CAN CAUSE SEVERE  
BURNS AND PRODUCE  
EXPLOSIVE GASES.*

*If the acid has been splashed  
on the skin, eyes or clothes  
flush with copious amounts of  
fresh water and seek  
immediate medical aid.*

Check the battery as follows:

Wear protective gloves and goggles.

Clean the top of the battery filler plug area.

Remove the filler plugs and check that the electrolyte level is 6.0-9.0mm (0.25-0.37in) above the tops of the separators.

If necessary top up with distilled water.

In cold weather distilled water should only be added immediately before running the engine.

Replace and tighten the filler plugs.

Check that the terminal connections are tight; petroleum jelly will help to protect them from corrosion.

## Mixer drum assembly

The drum is manufactured in two halves joined together by a drum clip. This allows either half to be replaced separately.

Some export machines are delivered with the drum cone and blades detached. This is to aid shipping.

There are two methods of reassembling the two halves of the drum, they are:

### 1 Assembling drum using special clamping tool.

*(The special clamping tool, part number 513204000 can be obtained from any Winget distributor.)*


- A** Bolt the two blades into the drum base **(1)**. Tighten the bolts with fingers only.
- B** Smear silicone sealant around the mating flanges of the cone **(2)** and drum base **(3)**. (see 'Specifications' for mixer drum sealant)

#### WARNING




*When applying silicone sealer, prevent contact with skin by wearing suitable gloves.*

- C** Lift the cone **(2)** over the blades and position it on the drum base **(3)**.
- D** Turn the cone until the two holes at the top of each blade **(4)** align with the holes in the cone. Fit bolts and tighten with fingers only.
- E** Smear silicone sealant around the inside face of the drum clip **(5)** (leave 150mm each end of the clip clear of sealant to avoid risk of fire when welding).
- F** Locate the drum clip around the periphery of the drum base and cone flange.




- G** Locate the clamping tool (7) into the two holes (8) of the drum clip. Tighten the tool securely using a suitable spanner.
- H** Centralise the bridge piece (9) on the drum clip between the jaws of the clamping tool.
- I** Weld the bridge piece (9) to the drum clip (5). Remove the clamping tool (7).
- J** Tighten securely all of the blade fixing bolts.



## 2 Assembling drum using a tourniquet.

- A** If the special clamping tool is not available a tourniquet can be used as illustrated by looping a length of rope through four blocks of wood (10), each block having a vee cut, and two holes to take the rope.
- B** Twist the rope around a bar (11) to tighten the drum clip.
- C** All other aspects of the assembly are the same as "Assembling the drum using special clamping tool".



**Mixer drum drive overhaul**

On reassembling the drum drive, after an overhaul, the following points must be observed:

**Note:** It is important to pack all sealed bearings with grease prior to assembly.


- A** Coat with an anti-seize compound the drum shaft (**j**) at points (**a**), and the screws (**j1**).
- B** The bearings (**b**) on either end of the bevel pinion shaft (**d**) are sealed for life and therefore require no maintenance.
- C** The bevel gears (**c**) are to be coated liberally with Open Gear Fluid.

**D** The bevel pinion assembly (**d**) must be set horizontally in the trunnion. Do this as follows:

Ensure that the drive chain (**f**) is correctly adjusted, then set the bevel pinion assembly (**d**) horizontal by adjusting shims (**e**).

**E** To adjust the mesh of the bevel pinion gears proceed as follows:

Allow the bevel gear to sit fully in mesh with the bevel pinion. Check the number of washers required to fill the gap (**g**) between the drum shaft flange and the trunnion face. Remove one washer from each side, fit screws (**h**) and tighten. Acceptable backlash 3mm. By using a combination of the varying thickness of washers and shims it is possible to fine tune the backlash.





## Lubricants

Mixers are factory filled with the following TOTAL oils.

Engine, LT1/LV1-10: lubricating oil	Rubia B 10W/30	1.3 litres
Yanmar L40/48: lubricating oil	Rubia B 10W/30	0.8 litres
<i>Note: In cold weather engines are to be filled with 10W oil to aid starting.</i>		
LT1/LV1-10: fuel		5.0 or 8.25 litres
Yanmar L40/48: fuel		2.5 litres

Electric motor bearing	Multis EP 2
Drive chains	Rubia B 20W/30
Bevel gears	Open gear fluid
Drum shaft	Anti-seize compound
Grease nipples	Multis EP 2
Linkages and hinges	Rubia B 20W/30

## Noise levels of mixers

(Measured in accordance with EC Directive 2000/14/EC)

LPA 83	LWA 102	Lister-Petter LT1/LV1-10
LPA 80	LWA 101	Yanmar L40/48 ARE-SE
LPA 80	LWA 98	Electric motor

## Drum speed

22 rpm (approximately)
------------------------


## Mixer drum sealant

Silicone sealant (part number V2000772)
---

## Engines and Motors

<b>Lister-Petter LT1/LV1-10</b> <b>(Standard)</b> 3 kW (4 hp) @ 1500 rpm	<b>Yanmar L40/48 ARE-SE</b> <b>(Option)</b> 2.5kW (3.4hp) @ 3000 rpm	<b>Electric motors 240v</b> <b>(Option)</b> 1.5 kW (2 hp) @ 1420 rpm
--	--	--


## Dimensions



<b>A</b> Overall length	2208 mm
<b>B</b> Overall width	1320 mm
<b>C</b> Overall height	1825 mm
<b>D</b> Loading height	1130 mm
<b>E</b> Discharge height	660 mm
-- Weight (approx)	600 kg

**Electrically driven mixers wiring circuit**

Electrical connections must only be made by a suitably qualified electrician.



**Notes:**

**Connections within electric motor**


- Link: U2 - Z2
- Red wire: U2
- Link: Z1 - O2
- Brown wire: O2
- Grey wire: Z1
- Yellow/Black wire: O1
- Yellow/White/Blue wire: U1

**Stop/Start Control Box**

Remove link from between 4 and 96

### Yanmar L40/L48 ARE-SE key start wiring circuit

In addition to the circuit shown below, the engine is fitted with its own loom.  
(see *Yanmar service literature*)



#### Wire colours

R Red  
B Black  
G Green  
W White  
Y Yellow

#### NOTE: Wire identification

The red wire to the battery is much thicker than the red wire to the start switch.


# **PARTS**

**Mixers manufactured  
UP TO  
serial number T200DL0547  
(November 1993)**

**Mixers manufactured  
FROM  
serial number T200DL0548  
(November 1993)**

**<<< TO BEGINNING OF BOOK**

# **200T MIXER**



**Mixers manufactured up to  
serial number T200DL0547  
(November 1993)**

# ***CONTENTS***

**A - 1    MAINFRAME**

**B - 1    DRUM & TRUNNION**

**C - 1    LISTER, drive assembly**

**C - 2    PETTER, drive assembly**

**C - 3    ELECTRIC MOTOR, drive assembly**


**C - 4    START/STOP SWITCHES, electric drive**

**D - 1    DECALS & PLATES**


**D - 3    SPECIAL TOOLS**

**INDEX, numerical**

**<<< TO BEGINNING OF PARTS**




Item	Part no	Serial no	Description	Qty
1	513315100	/ 0548	PIN, swivel	1
2	10S31		WASHER, flat	2
3	353308200		PIN, split	2
4	513315200		TOWBAR	1
5	63SO2K		BOLT	4
6	513324700		COLLAR, axle	4
7	7S02		NUT	10
8	17S03		WASHER, spring	8
9	1 1S05D		SCREW, set	10
10	61S05		NUT, self locking	10
11	267S07		WASHER, flat	10
12	513324900		AXLE, front	1
13	513325000		AXLE, rear	1
15	475115000		WHEEL, solid rubber, 16" x 4"	4
<b>Alternative wheel arrangement</b>				
16	475121000		WHEEL, pneumatic, 16" x 4" x 4 ply	4
---	475121002		TYRE	1
---	475121003		TUBE	1
17	475121001		BEARING, roller	1
17A	475122003		RETAINER	2
18	131S04		NIPPLE, grease	1
<b>Alternative wheel arrangement</b>				
19	513198500		WHEEL, pressed steel, 16" x 4"	4
20	11S03A		SCREW, set	4
21	7S03		NUT	10
22	17S04		WASHER, spring	12
24	11 S02A		SCREW, set	
25	513313100		MAINFRAME	1
26	513285000		BRACKET	1
27	513325500		LID, engine housing	1
28	513325800		STAY	1
29	513326000		PLATE	1
30	513205300		STOP, lid	2
31	513325900		PLATE	1
32	513248700		GUARD, chain	1
33	513325400		PLATE, closing	1
34	.....		GUARD, pulley ( <i>see Drive Assy. pages</i> )	
35	504600900		DECAL	1
36	513314700		BRACKET, swivel, front	1
37	11S03C		SCREW, set	1
38	267S05		WASHER, flat	1
39	11S03A		SCREW, set	10
40	11S04D		SCREW, set	2
41	7S03		NUT	5
42	17S04		WASHER, spring	4



**DRUM & TRUNNION**

**B - 1**


Item	Part no	Serial no	Description	Qty
1	513315400	/ 0548	HANDWHEEL	1
2	352806100		PIN, mills	1
3	513194400		PLUNGER	1
4	304708040		KEY, feather	1
5	403751016		SCREW, set	1
6	513315600		BEARING, handwheel	1
7	513315900		PLATE, backing	1
8	112803400		BUSH	2
9	513316000		SHAFT, tilting pinion	1
10	134105107		CHAIN, c/w connecting links	1
10A	134105002		LINK, connecting	2
11	513323902		DRUM TOP	1
12	513324100		DRUM CLIP	1
13	405101035		SCREW, set	4
14	17S05		WASHER, spring	4
15	513324200		BRIDGE PIECE	1
16	513324000		BASE, drum	1
17	513305200		GEAR, drum drive	1
18	17S06		WASHER, spring	10
19	134105070		CHAIN, c/w connecting link	1
19A	134105002		LINK, connecting	1
20	332719000		NUT, captive	10
21	405100616		SCREW, set	10
22	333501020		NIPPLE, grease, 90 degree	1
23	7S05		NUT	4
24	17S03		WASHER, spring	4
25	513323800		PLATE, retaining	1
26	513323700		INSERT	1
27	11 S05D		SCREW, set	6
28	88S42D		BEARING	1
29	132760000		CIRCLIP	1
30	7S04		NUT	8
31	17S05		WASHER, spring	8
32	402361025		SCREW	8
33	315803100		PLUG, grease	1
34	333102020		NIPPLE, grease, straight	2
35	11 S02AA		SCREW, set	4
36	513324300		BLADE, mixing	2
37	513316600		GUARD, chain, trunnion	1
38	513324400		WASHER, tab	1
39	513310100		SHAFT, drum	1
40	132313000		CIRCLIP	1
41	513308500	/ Dec 92	TRUNNION, (OBSOLETE: use 513354000)	
41A	513309300	/ Dec 92	BOSS, shaft support ( <i>Fits trunnion 513308500 only</i> )	1
41	513354000	Jan 93 /	TRUNNION	1



**DRUM & TRUNNION**

**B - 1**

Item	Part no	Serial no	Description	Qty
42	11S03B	/ 0548	SCREW, set	8
43	17S04		WASHER, spring	8
44	7S03		NUT	4
45	11S04B		SCREW, set	2
46	17S05		WASHER, spring	2
47	7S04		NUT	2
48	300110845		KEY, taper gib head	3
49	132775000		CIRCLIP	1
50	88S45D		BEARING	1
51	513313900		BACK PLATE, chain guard	1
52	513316400		GUARD, chain	1
54	513316500		GUARD, drum gear	1
55	12S26		WASHER, flat	AR
56	513310600		FLANGE, drum shaft	1
57	17S08		WASHER, spring	2
58	11SO6H		SCREW, set	2
59	513316300		GUARD, upper tilt chain	1
60	513310700		BEVEL PINION	1
61	132362000		CIRCLIP	1
62	88S05D		BEARING	2
63	513310300		SHAFT, bevel pinion	1
64	11SO5H		SCREW, set	2
65	513152400		PACKING PIECE (set of 2)	set
66	513305400		HOUSING, bevel pinion shaft	1
67	11SO6E		SCREW, set	2
68	513326300		WASHER, tab	1
69	88S15D		BEARING	2
70	513151900		PLATE, adjusting	1
71	513305300		CHAIN WHEEL, bevel pinion shaft	1
72	132725000		CIRCLIP	1
73	304708035		KEY, feather	1
74	513310500		SPROCKET, countershaft	1
75	11S05F		SCREW, set	2
76	513305500		BEARING, trunnion	1
77	72S09		NUT, welded	1
78	513310400		COUNTERSHAFT	1
79	513310800		CHAIN WHEEL, countershaft	1
			or	
79A	513331800		PULLEY, vee, countershaft	1
.....	V2000772		SEALING COMPOUND, (Between items 11 & 16 on assy)	AR



# DRIVE ASSEMBLY, LISTER

C - 1


Item	Part no	Serial no	Description	Qty
1	354051000	/ 0548	ENGINE, LISTER LT1	1
2	513326400		SPROCKET, engine	1
3	300204160		KEY, gib head	1
4	513248400		SHIMS	1 set
5	8S05J		BOLT	4
6	8S05E		BOLT	4
7	61S05		NUT, locking	8
8	267S07		WASHER, flat	8
9	105S0S		WASHER, taper	8
10	134105095		CHAIN	1
---	134105002		LINK, connecting	1
---	134105001		LINK, half	AR
11	513267500		PIPE, exhaust	1
12	354051005		CLAMP, pipe	1
13	153S01		CLAMP, pipe	1
14	267S04		WASHER, flat	2
15	513337900		BRACKET, exhaust	1
16	11S04B		SCREW, set	5
17	7S04		NUT	5
18	17S05		WASHER, spring	5
19	513256500		PIPE, 2.5" long	1
19A	513278200		PIPE, 140mm long	1
20	241102000		FITTING, elbow	1
21	241902000		FITTING, straight female	1
21A	241702000		PLUG, oil drain	1
22	513266900		GUARD, sprocket	1
27	513267400		CHANNEL, engine mount, (LH & RH)	2




# DRIVE ASSEMBLY, PETTER

C - 2

Item	Part no	Serial no	Description	Qty
1	354074900	/ 0548	ENGINE, PETTER AC1ZS	1
2	513267600		CHANNEL, engine mount	2
3	513248400		SHIMS	1 set
4	8S04E		BOLT	4
5	61S04		NUT, locking	4
6	267S06		WASHER, flat	4
7	105S04		WASHER, taper	4
8	8S05F		BOLT	4
9	61S05		NUT, locking	4
10	267S07		WASHER, flat	4
11	105S05		WASHER, taper	4
12	241102000		FITTING, elbow, female	2
15	513278000		PIPE, 45mm long	1
16	513278200		PIPE, 140mm long	1
16A	241702000		PLUG, oil drain	1
17	513326400		SPROCKET, 15T, engine	1
18	300204160		KEY, gib head	1
19	513267700		PIPE, exhaust	1
20	240308000		BEND, 90 degree, male	1
21	241908000		SOCKET	1
22	240708000		FITTING, elbow, 90 degree, m/f	1
23	513326100		SUPPORT, exhaust pipe	1
24	11S04B		SCREW, set	3
25	7S04		NUT	3
26	17S05		WASHER, spring	3
28	513205700		GUARD, sprocket	1
32	134105094		CHAIN	1
---	134105002		LINK, connecting	1
--	134105001		LINK, half	AR



Item	Part no	Serial no	Description	Qty
1	513335900		PLATE, motor mounting	1
2	513336000		SUPPORT, motor mounting	1
3	513333100		STUD, motor adjusting	1
4	513333500		PULLEY, 'V'	1
5	513336100		GUARD, pulley	1
7	11S05D		SCREW, set	2
8	59S04		NUT, nylon insert	4
9	8S05E		BOLT	2
10	267S07		WASHER, flat	2
11	11S04D		BOLT	4
12	59S03		NUT, nylon insert	4
13	7S05		NUT	4
14	17S06		WASHER, spring	4
15	304710840		KEY, parallel	1
16	57SO4D2		SCREW, socket, cone point	1
17	397400100		BELT 'V'	1
18	11S03A		SCREW	6
19	7S03		NUT	6
20	17S04		WASHER, spring	6
21	202438000		MOTOR	1
22	---		SWITCH, 'Start 1 Stop', (See page C - 4)	
23	---		SWITCH, 'stop' (See page C - 4)	
24	---		SCREW, (See page C - 4)	
25	---		SCREW, (See page C - 4)	
26	---		NUT, (See page C - 4)	
27	---		WASHER, (See page C - 4)	



Item	Part no	Serial no	Description	Qty
1	208392500		SWITCH, " Start / Stop	1
2	16SO6C		SCREW	2
3	267S03		WASHER, flat	2
4	17S02		WASHER, spring	2
5	7S01		NUT	2
6	205103400		SWITCH, " Stop " <b>OBSOLETE: use 208880000</b>	1
6	208870000	/ Oct-04	# SWITCH, stop, assembly <b># OBSOLETE: use 208880000</b>	1
6A	V602651	/ Oct-04	KEY, stop switch	1
6	208880000	Oct-04 /	SWITCH, stop, assembly	1
.....	208880000A	Oct-04 /	MUSHROOM key reset, c/w keys	1
.....	208880000B	Oct-04 /	CONTACTOR	1
.....	208880000C	Oct-04 /	ENCLOSURE	1
6A	V603623	Oct-04 /	KEY, stop switch	2
6B	133470000		PLUG, stop switch casing	1
7	11S01C	/ Oct-04	SCREW, set	2
7	11S01D	Oct-04 /	SCREW, set	
8	267S03		WASHER spring	2
9	17S02		WASHER, spring	2
10	7S01		NUT	2
11	131770010		TUBE, conduit, 20mm	.75 meter
12	131271000		COUPLING, 20mm	2
12A	133272000		NUT, locking	1
13	131766010		TUBE, conduit, 16mm	.75 meter
14	131270000		COUPLING, 16mm	2
15	131570016		FITTING, reducing	1
16	133266050		NUT, locking	1
20	144797000		CABLE, red (order by meter) AR	
21	144798000		CABLE, black (order by meter) AR	
22	144799000		CABLE, green/yellow (order by meter) AR	

# 1 200T

2

<b>WINGET</b>			
<small>WINGET LIMITED P.O. Box 89, Smethurst Lane, Bolton Lancs BL4 0WW Tel: (0204) 665165 Fax: (0204) 665206</small>			
Model			
Serial no.			
Engine no.	Power output		
Capacity	Weight kg.		
SRO	Year of man.		
<small>A Seddon Group Company</small>			

3

**DANGER**  
KEEP ENGINE HOUSING  
LID CLOSED WHEN  
ENGINE IS RUNNING

4

**SAFETY WARNING**

- 1 Before starting this machine, the operator should be familiar with the operating instructions issued by the manufacturer.
- 2 The manufacturer's rated capacity must never be exceeded.
- 3 Before carrying out any maintenance, servicing, or greasing, always ensure that the engine has been switched off. Never work on a machine while it is running.

5

**WATER TANK OPERATION**

**FILL** OPEN INLET VALVE UNTIL DESIRED QUANTITY SHOWS IN GAUGE GLASS

**DISCHARGE** PULL AND HOLD CHAIN DOWN UNTIL DISCHARGE IS COMPLETE

6

**DANGER**  
DO NOT WALK, STAND OR LEAN  
UNDER RAISED HOPPER UNLESS  
IT IS SECURELY PROPPED

7

**-HOPPER CONTROL-**  
TO RAISE HOPPER: PULL CONTROL LEVER UPWARDS.  
TO LOWER HOPPER: PUSH CONTROL LEVER DOWNWARDS.  
RELEASING THE LEVER WILL HALT THE HOPPER WHEN IT IS MOVING UP OR DOWN.  
DO NOT HOLD CONTROL IN 'RAISE' POSITION WHEN HOPPER IS FULLY UP.

7A

**HOPPER CONTROL**

TO LOWER HOPPER:- PULL CONTROL LEVER UPWARDS


TO RAISE HOPPER:- PUSH CONTROL LEVER DOWNWARDS

RELEASING THE LEVER WILL HALT THE HOPPER WHEN IT IS MOVING UP OR DOWN.


DO NOT HOLD CONTROL IN 'RAISE' POSITION WHEN HOPPER IS FULLY UP.

8


# WINGET



10 **DIESEL FUEL**



11 **HYDRAULIC OIL**




12

**WARNING**  
DO NOT TAMPER WITH THE PIPE CONNECTION ON THE LOAD CELL OR GAUGE. THIS IS A SEALED CIRCUIT AND MUST NOT BE INTERFERED WITH.

**DECALS & PLATES****D - 1**

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	V2003110	200T		
2	10317A05		PLATE, serial (OBSOLETE: use V2003037)	
2	V2003037		PLATE, serial	
---	15S01A		SCREW	
3	504600900		WARNING, engine housing	
4	504694600		WARNING, safety	
5	513331500		WATER TANK OPERATION	
6	513331600		DANGER, hopper	
7	555153600		HOPPER CONTROL	
7A	555283500		HOPPER CONTROL	
8	V2003104		LOGO (OBSOLETE: use V2003039)	
8	V2003039		LOGO, "WINGET"	
9	V2003103		STRIPE, bodywork, 3 colour (OBSOLETE: use V2003038)	
9A	V2003038		STRIPE, bodywork, 2 colour	
10	---		DIESEL FUEL (OBSOLETE: use item I 0A)	
10A	V2003101		DEISEL FUEL	
11	---		HYDRAULIC OIL (OBSOLETE: use item 11A)	
11A	V2003100		HYDRAULIC OIL	
12	515175000		WARNING, loadcell	
---	15S01A		SCREW	




**SPECIAL TOOLS**

---

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	513204000		CLAMP, drum clip	1

## 200T MIXER



# Numerical Index


[\*<<< TO BEGINNING OF SECTION\*](#)

<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>
112803400	B - 1	241902000	C - 1	513198500	A - 1
131270000	C - 4	241908000	C - 2	513204000	D - 3
131271000	C - 4	300110845	B - 1	513205300	A - 1
131570016	C - 4	300204160	C - 1	513205700	C - 2
131766010	C - 4	300204160	C - 2	513248400	C - 1
131770010	C - 4	304708035	B - 1	513248400	C - 2
132313000	B - 1	304708040	B - 1	513248700	A - 1
132362000	B - 1	304710840	C - 3	513256500	C - 1
132725000	B - 1	315803100	B - 1	513266900	C - 1
132760000	B - 1	332719000	B - 1	513267400	C - 1
132775000	B - 1	333102020	B - 1	513267500	C - 1
133266050	C - 4	333501020	B - 1	513267600	C - 2
134105001	C - 1	352806100	B - 1	513267700	C - 2
134105001	C - 2	353308200	A - 1	513278000	C - 2
134105002	B - 1	354051000	C - 1	513278200	C - 1
134105002	C - 1	354051005	C - 1	513278200	C - 2
134105002	C - 2	354074900	C - 2	513285000	A - 1
134105070	B - 1	397400100	C - 3	513305200	B - 1
134105094	C - 2	402361025	B - 1	513305300	B - 1
134105095	C - 1	403751016	B - 1	513305400	B - 1
134105107	B - 1	405100616	B - 1	513305500	B - 1
144797000	C - 4	405101035	B - 1	513310100	B - 1
144798000	C - 4	475115000	A - 1	513310300	B - 1
144799000	C - 4	475121000	A - 1	513310400	B - 1
202438000	C - 3	475121001	A - 1	513310500	B - 1
205103400	C - 4	475121002	A - 1	513310600	B - 1
208392500	C - 4	475121003	A - 1	513310700	B - 1
208870000	C - 4	475122003	A - 1	513310800	B - 1
240308000	C - 2	504600900	A - 1	513313100	A - 1
240708000	C - 2	504600900	D - 1	513313900	B - 1
241102000	C - 1	504694600	D - 1	513314700	A - 1
241102000	C - 2	513151900	B - 1	513315100	A - 1
241702000	C - 1	513152400	B - 1	513315200	A - 1
241702000	C - 2	513194400	B - 1	513315400	B - 1

<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>
513315600	B - 1	513336100	C - 3	17S02	C - 4
513315900	B - 1	513337900	C - 1	17S03	A - 1
513316000	B - 1	515175000	D - 1	17S03	B - 1
513316300	B - 1	555153600	D - 1	17S04	A - 1
513316400	B - 1	555283500	D - 1	17S04	B - 1
513316500	B - 1	10317A05	D - 1	17S04	C - 3
513316600	B - 1	105S04	C - 2	17S05	B - 1
513323700	B - 1	105S05	C - 2	17S05	C - 1
513323800	B - 1	105S0S	C - 1	17S05	C - 2
513323902	B - 1	10S31	A - 1	17S06	B - 1
513324000	B - 1	11S02A	A - 1	17S06	C - 3
513324100	B - 1	11S02AA	B - 1	17S08	B - 1
513324200	B - 1	11S05D	B - 1	267S03	C - 4
513324300	B - 1	11S01C	C - 4	267S04	C - 1
513324400	B - 1	11S03A	A - 1	267S05	A - 1
513324700	A - 1	11S03A	C - 3	267S06	C - 2
513324900	A - 1	11S03B	B - 1	267S07	A - 1
513325000	A - 1	11S03C	A - 1	267S07	C - 1
513325400	A - 1	11S04B	B - 1	267S07	C - 2
513325500	A - 1	11S04B	C - 1	267S07	C - 3
513325800	A - 1	11S04B	C - 2	513308500	B - 1
513325900	A - 1	11S04D	A - 1	513309300	B - 1
513326000	A - 1	11S04D	C - 3	513354000	B - 1
513326100	C - 2	11S05D	A - 1	56S07	C - 4
513326300	B - 1	11S05D	C - 3	57S04D2	C - 3
513326400	C - 1	11S05F	B - 1	59S03	C - 3
513326400	C - 2	11SO5H	B - 1	59S04	C - 3
513331500	D - 1	11SO6E	B - 1	61S04	C - 2
513331600	D - 1	11SO6H	B - 1	61S05	A - 1
513331800	B - 1	12S26	B - 1	61S05	C - 1
513333100	C - 3	131S04	A - 1	61S05	C - 2
513333500	C - 3	153S01	C - 1	63SO2K	A - 1
513335900	C - 3	15S01A	D - 1	72S09	B - 1
513336000	C - 3	16SO6C	C - 4	7S01	C - 4

<b><i>Part No.</i></b>	<b><i>Page</i></b>
7S02	A - 1
7S03	A - 1
7S03	B - 1
7S03	C - 3
7S04	B - 1
7S04	C - 1
7S04	C - 2
7S05	B - 1
7S05	C - 3
88S05D	B - 1
88S42D	B - 1
88S45D	B - 1
8S04E	C - 2
8S05E	C - 1
8S05E	C - 3
8S05J	C - 1
8S05F	C - 2
V2000772	B - 1
V2003037	D - 1
V2003038	D - 1
V2003039	D - 1
V2003100	D - 1
V2003101	D - 1
V2003103	D - 1
V2003104	D - 1
V2003110	D - 1

# **200T MIXER**




**Mixers manufactured from  
serial number T200DL0548  
(November 1993)**

# ***CONTENTS***


- A - 1** MAINFRAME & FRONT AXLE
- A - 2** PANELS
  
- B - 1** DRUM
- B - 2** TRUNNION & TILT WHEEL
- B - 3** DRUM DRIVE
  
- C - 1** LISTER- PETTER LT1-10/LV1-10, engine
- C - 2** ELECTRIC MOTOR, drive assembly
- C - 3** START / STOP SWITCHES, electric drive mixer
  
- C - 5** YANMAR L40/L48, electric start engine
- C - 6** ELECTRICS for Yanmar engine
  
- D - 1** DECALS & PLATES
- D - 2** SPECIAL TOOLS
  
- ..... **INDEX**, numerical

**<<< TO BEGINNING OF PARTS**




**MAINFRAME & FRONT AXLE****A - 1**

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	513357100		MAINFRAME	1
5	513324900		AXLE, front	1
6	353308200		PIN, split	2
7	10S31		WASHER, flat	2
8	513315100		PIN, swivel	1
10	513315200		BAR, towing	1
11	61S05		NUT, self-locking	2
12	11S05D		SCREW, set	2
15	475115000		WHEEL, solid rubber	4
			<i>or</i>	
16	513198500		WHEEL, steel	4
20	513324700		COLLAR	4
21	8S02H		BOLT	4
22	61S02		NUT, self-locking	4



**PANELS**

Item	Part no	Serial no	Description	Qty
1	V2003568	(year) / 1993	BOX, document <i>(document box now welded to item 45)</i>	1
2	101S07E	(year) / 1993	RIVET	2
5	513326000		PLATE	1
6	52S02C		SCREW, counter sunk head	2
7	11S03A		SCREW, set	2
8	17S04		WASHER, spring	4
9	7S03		NUT	4
15	513325800		STRUT, cover support	1
16	11S03D		SCREW, set	1
17	61S03		NUT, self-locking	1
20	513325500		COVER, engine/electric motor	1
21	7S04		NUT	2
22	267S06		WASHER, flat	2
23	11S04E		SCREW, set	2
25	513205300		STOP, lid	1
26	11S02A		SCREW, lid	2
27	61S02		NUT, self-locking	2
28	267S04		WASHER, flat	2
30	513325400		PLATE	1
31	7S03		NUT	4
32	17S04		WASHER, spring	4
33	11S03A		SCREW, set	4
40	513266900		GUARD, sprocket <i>(diesel engines)</i>	1
41	513336100		GUARD, sprocket <i>(electric motors)</i>	1
42	11S04B		SCREW, set	2
43	17S05		WASHER, spring	2
44	7S04		NUT	2
45	513248700		GUARD chain/belt	1
46	11S04B		SCREW, set	4
47	17S05		WASHER, spring	4
48	7S04		NUT	4
49	241859000		PLUG	1
50	513354600		PLATE	1
51	11S02A		SCREW, set	2
52	17S03		WASHER, spring	2
53	7S02		NUT	2
55	513285000	(year) / Aug-94	BRACKET, starting handle stowage <i>(bracket now welded to engine housing)</i>	1
60	513362600	0844 /	PLATE <i>(with Yanmar engines)</i>	1
61	11S02C	0844 /	SCREW, set <i>(with Yanmar engines)</i>	2
62	61S02	0844 /	NUT, Binx <i>(with Yanmar engines)</i>	2



**DRUM****B - 1**


<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	513323902		DRUM, top	1
2	513324000		DRUM, base	1
3	513324100		CLIP, drum	1
4	513324200		BRIDGE PIECE	1
5	V2000772		ADHESIVE, flexible	tube 1
10	513324300		BLADE	2
11	16S09D		SCREW, slotted panhead	8
12	17S05		WASHER, spring	8
13	7S04		NUT	8
15	513305200		GEAR, drum drive	1
15A	513371201		PACKER, shim, 0.5mm	AR
15B	513371202		PACKER, shim, 1.0mm	AR
15C	513371203		PACKER, shim, 2.0mm	AR
16	17S06		WASHER, spring	6
16A	267S07		WASHER, flat	6
17	11S05D		SCREW, set	6
20	132760000		CIRCLIP	1
21	88S42D		BEARING	1
22	132775000		CIRCLIP	1
23	88S45D		BEARING	1
24	513310100		SHAFT, drum	1
25	132313000		CIRCLIP	1
26	267S09		WASHER, flat, thick 3mm	AR
26A	267S20		WASHER, flat, thin 2mm	AR
26B			WASHER, shim, 0.5mm	AR
26C			WASHER, shim, 1.0mm	AR
27	513310600		PLATE	1
28	17S08		WASHER, spring	2
29	11S06H		SCREW, set	2
30	513326300		WASHER, locking strip	1
31	11S06E		SCREW, set	2



# TRUNNION & TILT WHEEL


B - 2

Item	Part no	Serial no	Description	Qty
1	513354000		TRUNNION	1
3	513316600		COVER, rear	1
4	11S02AA		SCREW, set	4
5	17S03		WASHER, spring	4
6	131S01		NIPPLE, grease	1
7	176S01		CAP, nipple	1
8	315803100		NIPPLE, grease	1
10	513316500		GUARD, drum gear	1
11	11S03B		SCREW, set	4
12	17S04		WASHER, spring	4
13	7S03		NUT	4
15	513316300		GUARD, upper	1
16	513316400		GUARD, lower	1
17	332719000		NUT, captive	10
18	11S02C		SCREW, set	10
19	17S03		WASHER, spring	10
20	131S02		NIPPLE, grease, 900	1
21	176S01		CAP, nipple	1
22	513323700		INSERT	1
23	513323800		PLATE	1
24	17S06		WASHER, spring	2
25	7S05		NUT	2
26	513315400		WHEEL, tilt	1
27	513194400		PLUNGER, locking	1
27A	513345300	July-03 /	SPRING	1
28	54S01A		PIN, roll	1
29	304710840		KEY, rectangular feather	1
30	57S06F1		SCREW, grub	1
31	11S04E		SCREW, set	4
32	17S05		WASHER, spring	4
33	513315600		BEARING, tilt wheel	1
34	513315900		PLATE	1
35	112803400		BUSH	2
36	513316000		SHAFT, tilt wheel	1
37	134105107		CHAIN, tilt wheel	1
38	134105002		LINK, connecting	2
39	134105001		LINK, half	AR



**DRUM DRIVE****B - 3**

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	300110845		KEY, taper gib	1
2	513310700		PINION	1
3	132362000		CIRCLIP	1
4	88S05D		BEARING	1
5	513310300		SHAFT	1
6	513305400		HOUSING	1
7	88S15D		BEARING	1
10	513152400		SHIM, pack	set 1
11	513324400		WASHER, locking strip	1
12	11S05H		SCREW, set	2
15	513298900		PLATE	1
16	11S04C		SCREW, set	2
17	267S06		WASHER, flat	2
18	17S05		WASHER, spring	2
19	7S04		NUT	2
20	513305300		SPROCKET	1
21	300110845		KEY, taber gib	1
22	134105070		CHAIN	1
23	134105002		LINK, connecting	1
24	134105001		LINK, half	1
30	132725000		CIRCLIP	1
31	304708035		KEY, rectangular feather	1
32	513310500		SPROCKET	1
33	132362000		CIRCLIP	1
34	88S05D		BEARING	1
35	513305500		HOUSING	1
36	11S05F		SCREW, set	2
37	17S06		WASHER, spring	2
38	7S05		NUT	2
39	513310400		SHAFT, counter	1
40	88S15D		BEARING	1
41	513310800		SPROCKET, (Lister-Petter engines)	1
			or	
42	513331800		PULLEY, (electric motors)	1
			or	
42A	371123000		PULLEY, (Yanmar engines)	1
42B	10S09		WASHER, flat	1
43	300110845		KEY, gib head	1
45	513211800		GUARD, bevel pinion	1
46	66S03AA		SCREW, set	1
47	41S05		WASHER, spring	1




Item	Part no	Serial no	Description	Qty
1	354051000	/ 1013	ENGINE, LT1-10 "Export" without anti kickback	1
1	354051000	1014 /	ENGINE, LV1-10 "Export" without anti kickback	1
1	354054100	/ 1013	ENGINE, LT1-10 "UK/EEC" with anti kickback	1
1	354054100	1014 /	ENGINE, LV1-10 "UK/EEC" with anti kickback	1
1A	EL60131350		FILTER, air	1
1B	EL20113118		FILTER, fuel	1
2A	.....		HANDLE, engine starting "Export", without anti kick back	1
2B	.....		HANDLE, engine starting "UK/EEC", with anti kick back	1


**NOTE: ENGINE CHANGE Lister-Petter LT1-10 to LV1-10**

Late in 2003 the Lister-Petter LT1-10 was superseded by the LV1-10. The engines as complete assemblies are interchangeable as are consumable items such as filters etc. Major items such as fuel injection pump, cylinder and piston, crankshaft, and conrod are different and when ordering spares it is important to quote the engine type.

3	61S05		NUT, "Binx", self-locking	4
4	267S07		WASHER, flat	4
5	105S05		WASHER, tapered	4
6	8S05J		BOLT	4
10	513267400		CHANNEL, engine mount	2
11	513248400		SHIMS	(set) 1
12	8S05E		BOLT	4
13	105S05		WASHER, tapered	4
14	267S07		WASHER, flat	4
15	61S05		NUT, "Binx", self-locking	4
20	513256500	/ 0609	PIPE, 63mm long	1
20	513359700	0610 / 0969	PIPE, 60mm long	1
21	241102000	/ 0609	FITTING, elbow	1
21	241104000	0610 / 0969	FITTING, elbow	1
22	513278200	/ 0609	PIPE, 140mm long	1
22	513359800	0610 / 0969	PIPE, 125mm long	1




Item	Part no	Serial no	Description	Qty
23	241902000	/ 0609	FITTING, straight, female	1
23	241904000	0610 / 0969	FITTING, straight, female	1
24	.....	/ 0969	PLUG, oil drain ( <i>See Eng. Parts Cat.</i> )	1
24A	513362800	0970 /	HOSE, flexible	1
24B	100S04	0970 /	SEAL, bonded	1
24C	127S04	0970 /	PLUG, blanking, oil drain	1
25	513326400		SPROCKET	1
25A	57S05D2		SCREW, grub	1
26	300204160		KEY	1
27	134105095		CHAIN	1
28	134105002		LINK,connecting	1
—	134105001		LINK, half	AR
30	354051005		CLAMP, exhaust	1
31	513267500		PIPE, exhaust	1
32	153S01		CLAMP, exhaust	1
33	267S04		WASHER, flat	2
34	513337900		BRACKET	1
35	11S04B		SCREW, set	1
36	17S05		WASHER, spring	1
37	7S04		NUT	1



**DRIVE ASSEMBLY, electric****C - 2**


<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	202438000		MOTOR, electric	1
2	11S04D		SCREW, set	4
3	7S04		NUT	4
4	17S05		WASHER, spring	4
5	304710840		KEY, parallel	1
6	57S04D2		SCREW, grub	1
7	513333500		PULLEY, vee	1
8	397400100		BELT, vee	1
10	513335900		PLATE, motor mounting	1
11	513333100		STUD	1
12	7S05		NUT	4
13	17S06		WASHER, spring	2
14	8S05E		BOLT	2
15	267S07		WASHER, flat	2
16	59S04		NUT, nylon insert	2
20	513336000		SUPPORT, motor mounting	1
21	11S05D		SCREW, set	2
22	267S07		WASHER, flat	2
23	59S04		NUT, nylon insert	2



**START / STOP SWITCHES, electric drive mixers**


**C - 3**

Item	Part no	Serial no	Description	Qty
				1
1	208392500		SWITCH, " Start / Stop "	2
2	16S06C		SCREW	2
3	267S03		WASHER, flat	2
4	17S02		WASHER, spring	
5	7S01		NUT	2
6	208870000	/ Oct-04	# SWITCH, stop, assembly # <b>OBSOLETE: use 208880000</b>	1
6A	V602651	/ Oct-04	KEY, stop switch	1
6	208880000	Oct-04 /	SWITCH, stop, assembly	1
.....	208880000A	Oct-04 /	MUSHROOM key reset, c/w keys	1
.....	208880000B	Oct-04 /	CONTACTOR	1
.....	208880000C	Oct-04 /	ENCLOSURE	1
6A	V603623	Oct-04 /	KEY, stop switch	2
6B	133470000		PLUG, stop switch casing	1
7	11S01C	/ Oct-04	SCREW, set	2
7	11S01D	Oct-04 /	SCREW, set	
8	267S03		WASHER, flat	2
9	17S02		WASHER, spring	2
10	7S01		NUT	2
11	131770010		TUBE, conduit, 20mm	.75 metre
12	131271000		COUPLING, 20mm	2
12A	133272000		NUT, locking	1
13	131766010		TUBE, conduit, 16mm	.75 metre
14	131270000		COUPLING, 16mm	2
15	131570016		FITTING, reducing	1
16	133266050		NUT, locking	1
20	144797000		CABLE, red	order by metre
21	144798000		CABLE, black	order by metre
22	144799000		CABLE, green/yellow	order by metre



## Engine &amp; mounts


Item	Part no	Serial no	Description	Qty
<b>Note: For Battery, start switch &amp; loom, see page C-6</b>				
1	V2005210	0844 /	ENGINE, Yanmar L40/L48 ARE-SE	1
2	513361600		PIPE, exhaust	1
3	153S02		CLAMP, exhaust	1
4	267S04		WASHER, flat	1
5	17S03		WASHER, spring	1
10	513362300	/ 0996	ROD, engine stop	1
11	254820000	/ 0996	GROMMET, open ( <i>Fitted in eng. cover</i> )	1
12	7S02	/ 0996	NUT	1
13	V2005213	/ 0996	HANDLE, 'T', engine stop	1
14	267S04	/ 0996	WASHER, flat	2
15	44S02B	/ 0996	PIN, split	2
19	57S04D2		SCREW, grub	1
20	V2005220		PULLEY	1
21	V2004220		WASHER, 'Special'	1
22	17S04		WASHER, spring	1
23	11S03D		SCREW, set	1
24	305110550		KEY, parallel	1
25	397400500		BELT, 'V'	1
26	.....		CABLE, negative ( <i>See page C-6</i> )	1
30	8S03D		BOLT	4
31	267S05		WASHER, flat	8
32	61S03		NUT, self- locking "Binx"	4
35	267S07		WASHER, flat	14
36	17S06		WASHER, spring	2
37	7S05		NUT	6
38	61S05		NUT, self- locking "Binx"	5
39	11S05D		SCREW, set	3
40	513333100		STUD	2
45	513361800		PLATE, engine mounting	1
46	8S04D		BOLT	2
47	267S06		WASHER, flat	2
48	61S04		NUT, self- locking "Binx"	2
49	513358800		SUPPORT, bracket	1
50	513362500		BAR, engine mount	1
51	325S04	0996 /	ADAPTOR, male/male	1
52	298S05	0996 /	SEAL, bonded	1
53	31S02LL	0996 /	HOSE, engine oil drain	1
54	127S03	0996 /	PLUG, blanking	1



## Battery, start switch &amp; loom

Item	Part no	Serial no	Description	Qty
26	V2005211	0844 /	CABLE, negative	1
35	267S07		WASHER, flat	2
36	17S06		WASHER, spring	1
37	7S05		NUT	1
60	109S11		BATTERY, 12 volt	1
61	11S02B		SCREW, set	1
62	267S04		WASHER, flat	1
63	17S03		WASHER, spring	1
64	7S02		NUT	1
65	513362000		COVER, battery	1
66	513361900		CLAMP, battery	1
67	52S02E		SCREW, counter sunk	2
68	513361700		ROD, battery clamp	2
69	61S02		NUT, self-locking, 'Binx'	2
70	V2003561		SWITCH, start, c/w keys	1
71	V601179		KEY	2
72	V2003540		KEY RING	1
73	513359200		BRACKET, start switch	1
74	11S03A		SCREW, set	2
75	61S03		NUT, self-locking, 'Binx'	2
80	513362200		LOOM	1
81	V2005209		CLIP, 'P'	1
82	17S04		WASHER, spring	1
83	11S03A		SCREW, set	1

# 1 200 T




**2 WINGET** WINGET LIMITED  
 P.O. Box 89, Smethurst Lane, Bolton Lancs BL4 0WW  
 Tel: (0204) 665165 Fax: (0204) 665206

Model			
Serial no.			
Engine no.	Power output		
Capacity	Weight kg.		
SRO	Year of man.		

A Seddon Group Company

**3 DANGER**  
 KEEP ENGINE HOUSING  
 LID CLOSED WHEN  
 ENGINE IS RUNNING




**4 SAFETY WARNING**

- 1 Before starting this machine, the operator should be familiar with the operating instructions issued by the manufacturer.
- 2 The manufacturer's rated capacity must never be exceeded.
- 3 Before carrying out any maintenance, servicing, or greasing, always ensure that the engine has been switched off. Never work on a machine while it is running.



# 5 WINGET













**6A**

	<p>IN COLD WEATHER, IF THE ENGINE IS HARD TO START, REMOVE THE RUBBER PLUG ON THE ROCKER COVER AND ADD NO MORE THAN 2cc OF ENGINE OIL BEFORE STARTING AS RECOMMENDED IN THE ENGINE OPERATORS HANDBOOK. ALWAYS REFIT THE RUBBER PLUG.</p> <p>V2005276</p>
--	--

**DECALS & PLATES****D - 1**

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	V2003110		"200T"	2
2	V2003037		PLATE, serial number	1
-	15S01A		SCREW	4
3	504600900		WARNING, engine housing	1
4	504694600		WARNING, safety	2
5	V2003039		LOGO, "WINGET"	3
6	V2003038		STRIPE, bodywork	2
6A	V2005276		ENGINE COLD STARTING	1
7	V2003101		DIESEL FUEL	1
8	V2003665		SLING POINTS	1
9	V2003598		BRITISH MADE	1



**DECALS & PLATES****D - 1A**

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
10	V2004302		ENGINE STOP	1
11	V2004307		ELECTRICAL HAZARD	2
12	V2004137		EAR PROTECTION	2
13	V2004744		EYE PROTECTION	2
14	V2004227		BATTERY ISOLATOR	1
15	V2004229		OPERATORS HANDBOOK	2
16	V2004282		HOT SURFACES	1
17	V2004289		HANDS CLEAR	2
18	V2005208		ENGINE STARTING PROCEDURE	1
19	V2004288		REMOVE STARTING HANDLE	1
20	V2004223		"CE" MARK <i>(Only applied to EC specification machines)</i>	1
21	V2004235		NEGATIVE EARTH	1
22	V2004281		ENTRAPMENT	1
23	V2003574		83 LPA	
24	V2004132		102 LWA	1
				1

26

	LWA
<b>101</b> dB	
<small>V2005311</small>	

27

	L <sub>pA</sub>
<b>80</b> dB	
<small>V2004180</small>	

28

	LWA
<b>98</b> dB	
<small>V2004287</small>	

29

	<b>TO STOP THE ENGINE PRESS THE RED BUTTON</b>
<small>V2005290</small>	

30


	<b>WARNING</b> <b>WHEN TRANSPORTING THE MIXER BY FORKLIFT, ENSURE BOTH FORKS ENGAGE THE MAINFRAME LIFTING POINTS.</b>
<small>V2005281</small>	

31

	<b>THE RECOIL STARTER SHOULD ONLY BE USED AS AN "EMERGENCY" MEANS OF STARTING THE ENGINE AND SHOULD BE USED WITH CARE. BE AWARE THAT STARTING THE ENGINE WITH THE RECOIL DUE TO THE ABSENCE OF THE START KEY OR BATTERY OR BECAUSE THE BATTERY IS DISCHARGED WILL RESULT IN DAMAGE TO THE ALTERNATOR.</b>
<small>V2005214</small>	

**DECALS & PLATES****D - 1B**


<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
26	V2005311		101 LWA	1
27	V2004130		80 LpA	1
28	V2004297		98 LWA	1
29	V2005290		STOP ENGINE WITH RED BUTTON	1
30	V2005291		TRANSPORTING WITH FORKS	1
31	V2005214		RECOIL STARTER WARNING	1



**SPECIAL TOOLS**

<b>Item</b>	<b>Part no</b>	<b>Serial no</b>	<b>Description</b>	<b>Qty</b>
1	513204000		CLAMP, drum clip	1

## **200T MIXER**



# **Numerical Index**

**<<< TO BEGINNING OF SECTION**

<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>
112803400	B - 2	254820000	C - 5	513298900	B - 3
131271000	C - 3	300110845	B - 3	513305200	B - 1
131570016	C - 3	300110845	B - 3	513305300	B - 3
131766010	C - 3	300204160	C - 1	513305400	B - 3
131770010	C - 3	304708035	B - 3	513305500	B - 3
132313000	B - 1	304710840	B - 2	513310100	B - 1
132362000	B - 3	304710840	C - 2	513310300	B - 3
132725000	B - 3	305110550	C - 5	513310400	B - 3
132760000	B - 1	315803100	B - 2	513310500	B - 3
132775000	B - 1	332719000	B - 2	513310600	B - 1
133266050	C - 3	353308200	A - 1	513310700	B - 3
134105001	B - 2	354051000	C - 1	513310800	B - 3
134105001	B - 3	354051005	C - 1	513315100	A - 1
134105001	C - 1	354054100	C - 1	513315200	A - 1
134105002	B - 2	371123000	B - 3	513315400	B - 2
134105002	B - 3	397400100	C - 2	513315600	B - 2
134105002	C - 1	397400500	C - 5	513315900	B - 2
134105070	B - 3	475115000	A - 1	513316000	B - 2
134105095	C - 1	504600900	D - 1	513316300	B - 2
134105107	B - 2	504694600	D - 1	513316400	B - 2
144797000	C - 3	513152400	B - 3	513316500	B - 2
144798000	C - 3	513194400	B - 2	513316600	B - 2
144799000	C - 3	513198500	A - 1	513323700	B - 2
202438000	C - 2	513204000	D - 2	513323800	B - 2
208392500	C - 3	513205300	A - 2	513323902	B - 1
208870000	C - 3	513211800	B - 3	513324000	B - 1
208870000A	C - 3	513248400	C - 1	513324100	B - 1
208870000B	C - 3	513248700	A - 2	513324200	B - 1
208870000C	C - 3	513256500	C - 1	513324300	B - 1
241102000	C - 1	513266900	A - 2	513324400	B - 3
241104000	C - 1	513267400	C - 1	513324700	A - 1
241859000	A - 2	513267500	C - 1	513324900	A - 1
241902000	C - 1	513278200	C - 1	513325400	A - 2
241904000	C - 1	513285000	A - 2	513325500	A - 2

<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>
513325800	A - 2	11S01C	C - 3	16S09D	B - 1
513326000	A - 2	11S02A	A - 2	176S01	B - 2
513326300	B - 1	11S02A	A - 2	17S02	C - 3
513326400	C - 1	11S02AA	B - 2	17S03	A - 2
513331800	B - 3	11S02B	B - 2	17S03	B - 2
513333100	C - 2	11S02B	C - 6	17S03	C - 5
513333100	C - 5	11S02C	A - 2	17S03	C - 6
513333500	C - 2	11S03A	A - 2	17S04	A - 2
513335900	C - 2	11S03A	C - 6	17S04	B - 2
513336000	C - 2	11S03A	C - 6	17S04	C - 5
513336100	A - 2	11S03B	B - 2	17S04	C - 6
513337900	C - 1	11S03D	A - 2	17S05	A - 2
513354000	B - 2	11S03D	C - 5	17S05	B - 1
513354600	A - 2	11S04B	A - 2	17S05	B - 2
513357100	A - 1	11S04B	C - 1	17S05	B - 3
513358800	C - 5	11S04C	B - 3	17S05	C - 1
513359200	C - 6	11S04D	C - 2	17S05	C - 2
513359700	C - 1	11S04E	A - 2	17S06	B - 1
513359800	C - 1	11S04E	B - 2	17S06	B - 2
513361600	C - 5	11S05D	A - 1	17S06	B - 3
513361700	C - 6	11S05D	B - 1	17S06	C - 2
513361800	C - 5	11S05D	C - 2	17S06	C - 5
513361900	C - 6	11S05D	C - 5	17S06	C - 6
513362000	C - 6	11S05F	B - 3	17S08	B - 1
513362200	C - 6	11S05H	B - 3	267S03	C - 3
513362300	C - 5	11S06E	B - 1	267S04	A - 2
513362500	C - 5	11S06H	B - 1	267S04	C - 1
513362600	A - 2	127S04	C - 1	267S04	C - 5
100S04	C - 1	131S01	B - 2	267S04	C - 6
101S07E	A - 2	131S02	B - 2	267S05	C - 5
105S05	C - 1	153S01	C - 1	267S06	A - 2
109S11	C - 6	153S02	C - 5	267S06	B - 3
10S09	B - 3	15S01A	D - 1	267S06	C - 5
10S31	A - 1	16S06C	C - 3	267S07	B - 1

<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>	<b>Part No.</b>	<b>Page</b>
267S07	C - 1	7S03	B - 2	V2004132	D - 1A
267S07	C - 2	7S04	A - 2	V2004137	D - 1A
267S07	C - 5	7S04	B - 1	V2004220	C - 5
267S07	C - 6	7S04	B - 3	V2004223	D - 1A
267S09	B - 1	7S04	C - 1	V2004227	D - 1A
41S05	B - 3	7S04	C - 2	V2004229	D - 1A
44S02B	C - 5	7S05	B - 2	V2004235	D - 1A
513362800	C - 1	7S05	B - 3	V2004281	D - 1A
52S02C	A - 2	7S05	C - 2	V2004282	D - 1A
52S02E	C - 6	7S05	C - 5	V2004288	D - 1A
54S01A	B - 2	7S05	C - 6	V2004289	D - 1A
56S07	C - 3	88S05D	B - 3	V2004297	D - 1B
57S04D2	C - 2	88S15D	B - 3	V2004302	D - 1A
57S04D2	C - 5	88S42D	B - 1	V2004307	D - 1A
57S05D2	C - 1	88S45D	B - 1	V2004744	D - 1A
57S06F1	B - 2	8S02H	A - 1	V2005208	D - 1A
59S04	C - 2	8S03D	C - 5	V2005209	C - 6
61S02	A - 1	8S04D	C - 5	V2005210	C - 5
61S02	A - 2	8S05E	C - 1	V2005211	C - 6
61S02	C - 6	8S05E	C - 2	V2005213	C - 5
61S02	A - 2	8S05J	C - 1	V2005220	C - 5
61S03	A - 2	V2000772	B - 1	V2005276	D - 1
61S03	C - 5	V2003037	D - 1	V2005290	D - 1B
61S03	C - 6	V2003038	D - 1	V2005291	D - 1B
61S04	C - 5	V2003039	D - 1	V2005311	D - 1B
61S05	A - 1	V2003101	D - 1	V601179	C - 6
61S05	C - 1	V2003110	D - 1		
61S05	C - 5	V2003540	C - 6		
66S03AA	B - 3	V2003561	C - 6		
7S01	C - 3	V2003568	A - 2		
7S02	A - 2	V2003574	D - 1A		
7S02	C - 5	V2003598	D - 1		
7S02	C - 6	V2003665	D - 1		
7S03	A - 2	V2004130	D - 1B		

## **CALIFORNIA**

### **Proposition 65 Warning**

**Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects, and other reproductive harm.**